



Side Stage Area
Height 17'-5/8"

Exit
Stage Right

14'-0 1/2"
Stage "Elephant Door"

Exit
Stage Left
Spiral Staircase
(to Mid-Rail/Fly Gallery)

PVC Cyclorama

Up Stage
Black Out

Fly System

Centre Line

16'-11"

13'-1"

13'-1"

14'-11"

Leg to Leg distance
35'-0"

41'-0"

Main Curtain
(guillotine only)

Exit

Gala Lift
Stage Extension Level
Audience Level
Orchestra Level

8'-3"

33'-8"

Ladder Storage

No.	Item
48	CYC
47	ELECTRIC 6
46	PVC PLASTIC
45	US BLACK OUT
44	BLACK SCrim
43	LEGs 5
42	ELECTRIC 5
41	
40	
39	BORDER 5
38	
37	ELECTRIC 4
36	
35	
34	LEGs 4
33	BORDER 4
32	
31	SIDE FILLS
30	9X16 PROJECTION SCREEN
29	
28	
27	
26	ELECTRIC 3
25	
24	
23	LEGs 3
22	BORDER 3 (BLK OUT)
21	
20	
19	
18	
17	
16	ELECTRIC 2
15	
14	
13	LEGs 2
12	BORDER 2
11	
10	SIDE FILLS
9	
8	
7	
6	ELECTRIC 1
5	
4	PROJECTOR
3	LEGs 1
2	BORDER 1 (BLK OUT)
1	HOUSE CURTAIN